Numerical on Hardness

Simple Hardness

1. How many grams of MgSO₄ dissolved per litre gives 84ppm of hardness. Ans: 0.1008 gram

2. A water sample contains 204ppm of CaSO₄. Calculate the hardness. Ans: 150ppm.

3. Calculate temporary, permanent and total hardness of water sample containing: Mg(HCO₃)₂=14.6mg/L, MgCl₂=19.0mg/L, MgSO₄=24mg/L, CaCL₂=22.2mg/L, NaCl=5.35 mg/L.

Ans: 10ppm, 60ppm, 70ppm.

4. A water sample on analysis was found to contain the following impurities: $Mg(HCO_3)_2=7.3mg/L$, $Ca(HCO_3)_2=16.2mg/L$, $MgSO_4=12.0mg/L$, $CaSO_4=13.6,g/L$, $K_2SO_4=5.35$ mg/L. Calculate temporary, permanent and total hardness of water sample.

Ans: 15ppm, 20ppm, 35ppm.

Zeolite Process

A zeolite bed on softening 7000 liters of hard water required 60 liters of 10% NaCl solution for regeneration.
 Calculate the hardness of water in ppm.

Ans: 732.6 ppm.

2. A water sample having hardness 250ppm was softened by zeolite process. The exhausted zeolite bed required 50 liters of 15% NaCl solution for regeneration. Calculate the quantity of water softened using the zeolite bed.

Ans: 25641 liters.

- A zeolite bed got exhausted after softening 5000 liters of hard water. Hardness of water was 250ppm. How many liters of 10% NaCl solution would be required to regenerate zeolite bed.
 Ans: 14.7 liters.
- **4.** A zeolite softener was 90% exhausted when 10000 liters of hard water was passed through it. The softener required 200 liters of NaCl of strength 5gram/L. Find the hardness of water.

 Ans: 85.47ppm.

Lime-Soda Process

1. Calculate the amount of lime and soda required for softening of 50000 liters of hard water containing: Mg(HCO₃)₂=14.6mg/L, MgCl₂=19.0mg/L, MgSO₄=24mg/L, CaCL₂=22.2mg/L.

Ans: Lime: 2.22 kg, and Soda: 3.18kg

2. Calculate the amount of lime and soda required for softening of 10000 liters of hard water containing: $Mg(HCO_3)_2=7.3mg/L$, $Ca(HCO_3)_2=16.2mg/L$, $MgSO_4=12.0mg/L$, $CaSO_4=13.6,g/L$, HCL=3.65 mg/L.

Ans: Lime: 0.259 kg, and Soda: 0.265kg

3. Calculate the amount of lime (74% pure) and soda (90% pure) required for softening of 50000 liters of hard water containing: Mg(HCO₃)₂=73.0mg/L, CaCl₂=222.0mg/L, MgSO₄=120.0mg/L, Ca(NO₂)₂=164.0mg/L.

Ans: Lime: 1.0 kg, and Soda: 2.356kg

Calculate the amount of lime and soda required for softening of 15000 liters of hard water which analyzed as follows: Temporary Ca Hardness=20ppm, Total Permanent Hardness=15ppm and Permanent Mg Hardness=10ppm.
 Ans: Lime: 330gm, and Soda: 238.5gm